

730 HP Disinfectant Cleaner

For use with WAXIE Solution Station® dispensers.



DESCRIPTION

730 HP Disinfectant Cleaner is a one-step hospital-use germicidal† disinfectant cleaner and deodorant designed for general cleaning, disinfecting, and controlling mold and mildew odors on hard, non-porous surfaces when used according to disinfection directions. It cleans quickly by removing dirt, grime, body oils and other common soils found in hospitals, nursing homes, acute and long-term care facilities, office buildings, schools and colleges universities, day care centers, medical, dental offices, funeral homes, transportation facilities, train depots, bus stations, airports, cruise ships, casinos, correctional facilities, athletic facilities, playgrounds, locker rooms, health clubs, exercise equipment, barber/beauty (salons) (shops), veterinary clinics, pet shops, animal life science laboratories, hotels, motels, public areas and restrooms, foodservice establishments and federally inspected meat and poultry establishments, food processing industrial and commercial buildings only on hard, non-porous non-food contact surfaces. Effective against ‡SARS-Related Coronavirus 2 (SARS-CoV-2) (the virus that causes COVID-19) in 1 minute on hard, nonporous surfaces. † Pseudomonas aeruginosa, Salmonella enterica, Norovirus.

SPECIFICATIONS

	AS SOLD	USE DILUTION
Appearance	Clear, colorless liquid	Clear, colorless liquid
Odor	Characteristic	Characteristic
pH	Not determined	Not determined
Melting Point/Freezing Point	0°C (32°F)	0°C (32°F)
Initial Boiling Point/Boiling Range	100°C (212°F)	100°C (212°F)
Flash Point	Not applicable	Not applicable
Flammability	Not applicable	Not applicable
Relative Density (Density)	1.04	Approx. 1.00
Solubility	Not determined	Not determined
VOC		Not determined

ACTIVE INGREDIENTS:

Hydrogen Peroxide 4.25%

OTHER INGREDIENTS:

..... 95.75%
TOTAL: 100.000%

DIRECTIONS FOR USE

Refer to the product label for complete usage directions.

DILUTION RATIO: 1:64 (2 oz/gal) of water on hose fill mode. Each bottle makes 52 gallons. Each case makes 206 gallons.

Item: 170059 3L 4/cs
 Secondary Label: 170059LBL each

FEATURES & BENEFITS

- Hydrogen Peroxide Disinfectant Cleaner
- For use with electrostatic sprayers
- ONE-STEP DISINFECTANT
- NON-DULLING TO FLOOR FINISHES
- Cleans, Deodorizes and Brightens in One Step
- Fragrance Free Formula
- Evaporates completely
- Leaves no visible residue
- Kills odor causing bacteria

PRODUCT REGISTRATIONS

- EPA Registration No. 45745-11-14994



The Most Trusted Name In Clean. Since 1945.

Corporate Headquarters | 9353 Waxie Way | San Diego, CA 92123

(800) 995-4466 | www.waxie.com

© 2022 WAXIE Sanitary Supply 1122

730 HP Disinfectant Cleaner

For use with WAXIE Solution Station® dispensers.



SAFETY INFORMATION

PERSONAL PROTECTIVE EQUIPMENT:

Concentrate B – Safety Glasses & Gloves



Ready-to-Use Not applicable

Read the Safety Data Sheet (SDS) and product label before use. The SDS and product label contain hazard warnings, precautionary statements and first aid procedures. SDS documents are available online at www.waxie.com or by calling (800) 995-4466.

For sale to, use and storage by service professionals only. Keep out of reach of children.

HOTLINE NUMBER: You may contact Chem-Tel at (800) 255-3924 for emergency medical treatment information.

DISINFECTION & SANITIZATION CLAIMS

MICRO-ORGANISMS: At a 1:64 dilution (2 oz of product per gallon of water), in the presence of 200 ppm hard water, 5% blood serum load and 10 minute contact time, unless otherwise noted, this product kills the following on hard, nonporous inanimate surfaces:

BACTERICIDAL ACTIVITY	Peroxide Activity Level	Contact Time	Dilution (oz/gl)
Escherichia coli O157:H7	660 PPM	10 Minutes	2 oz/gl
Escherichia faecalis (VRE)	660 PPM	10 Minutes	4 oz/gl
Listeria monocytogenes*	830–1328 PPM	10 Minutes	2.5 oz/gl or 2.5-4 oz/gl
Pseudomonas aeruginosa	660 PPM	10 Minutes	2 oz/gl
Salmonella enterica	660 PPM	10 Minutes	2 oz/gl
Staphylococcus aureus	660 PPM	10 Minutes	2 oz/gl
Staphylococcus aureus, Methicillin resistant (MRSA)	660 PPM	10 Minutes	2 oz/gl
Staphylococcus aureus (CA-MRSA) USA300	660 PPM	10 Minutes	2 oz/gl
Staphylococcus aureus (CA-MRSA) USA400	660 PPM	10 Minutes	2 oz/gl
Staphylococcus epidermidis, Methicillin-resistant (MRSE)	660 PPM	10 Minutes	2 oz/gl
Streptococcus pneumoniae	660 PPM	10 Minutes	2 oz/gl
Streptococcus pneumoniae, Penicillin-resistant (PRSP)	660 PPM	10 Minutes	2 oz/gl

FUNGICIDAL ACTIVITY	Peroxide Activity Level	Contact Time	Dilution (oz/gl)
Trichophyton interdigitale (Athlete's foot fungus)	2650 PPM	10 Minutes	8 oz/gl

NON-FOOD CONTACT SANITIZATION	Peroxide Activity Level	Contact Time	Dilution (oz/gl)
Enterobacter aerogenes	330 PPM	5 Minutes	1 oz/gl
Salmonella enterica	330 PPM	5 Minutes	1 oz/gl

* Indicates that a dilution of (2.5oz) or (2.5-4oz.) per gallon of water is required for this claim



The Most Trusted Name In Clean. Since 1945.

Corporate Headquarters | 9353 Waxie Way | San Diego, CA 92123

(800) 995-4466 | www.waxie.com

© 2022 WAXIE Sanitary Supply 1122

730 HP Disinfectant Cleaner

For use with WAXIE Solution Station® dispensers.



DISINFECTION & SANITIZATION CLAIMS (CONTINUED)

MICRO-ORGANISMS: At a 1:64 dilution (2 oz of product per gallon of water), in the presence of 200 ppm hard water, 5% blood serum load and 10 minute contact time, unless otherwise noted, this product kills the following on hard, nonporous inanimate surfaces:

VIRUCIDAL ACTIVITY	Peroxide Activity Level	Contact Time	Dilution (oz/gl)
Adenovirus Type 8	660 PPM	5 Minutes	2 oz/gl
Hepatitis B Virus (HBV) (Duck Hepatitis B Virus as the surrogate)	660 PPM	5 Minutes*	2 oz/gl
Hepatitis C Virus (HCV) (Bovine Viral Diarrhea Virus as the surrogate)	660 PPM	5 Minutes	2 oz/gl
Herpes simplex virus Type 1	660 PPM	5 Minutes	2 oz/gl
Herpes simplex virus Type 2	660 PPM	5 Minutes	2 oz/gl
HIV-1 (AIDS Virus)	660 PPM	1 Minute	2 oz/gl
H1N1 Influenza A Virus	660 PPM	1 Minute	2 oz/gl
Human Coronavirus	660 PPM	5 Minutes	2 oz/gl
Norovirus (Feline Calicivirus as the surrogate)	660 PPM	5 Minutes	2 oz/gl
Rhinovirus Type 37	660 PPM	5 Minutes	2 oz/gl
Rotavirus	660 PPM	5 Minutes	2 oz/gl
SARS-Related Coronavirus 2 (SARS-CoV-2) (the virus that causes COVID-19)**	660 PPM	1 Minute	2 oz/gl

ANIMAL PREMISE VIRUCIDAL PERFORMANCE	Peroxide Activity Level	Contact Time	Dilution (oz/gl)
Canine Parvovirus	2650 PPM	10 Minutes	8 oz/gl
Murine Norovirus (MNV-1)	1325 PPM	10 Minute	4 oz/gl

* 5 minute contact time on pre-cleaned surfaces

** SARS-Related Coronavirus 2 claim was tested in 400 PPM



The Most Trusted Name In Clean. Since 1945.

Corporate Headquarters | 9353 Waxie Way | San Diego, CA 92123

(800) 995-4466 | www.waxie.com

© 2022 WAXIE Sanitary Supply 1122